




Wedge Anchor Bolt Installation

Installation

Step-By-Step

Installation Instructions



1. Drill the hole, whose diameter equals the anchor diameter, perpendicular to the work surface. To assure full holding power, do not ream the hole or allow the drill to wobble.
2. Drill the hole deeper than the intended embedment, but not closer than two diameters to the opposite surface of the concrete.
3. A clean hole is necessary for proper performance. Clean the hole using a nylon brush and compressed air.
4. Assemble the nut and washer so that the top of the nut is flush with the top of the anchor. Drive the anchor through the material to be fastened so that the nut and washer are flush with the surface of the material.
5. Tighten the nut, or head, 3 to 5 turns past the hand tight position. Installation of the wedge anchor bolts with a torque wrench is recommended for optimum performance. Refer to installation data tables.*

NOTE: Always wear safety glasses. Follow drill manufacturer's instructions. Use only solid carbide-tipped drill bits meeting ANSI B212.15 diameter standards.

Installation Data Tables

*Torque Values

Anchor Dia. (In.)	Recommended Setting Torque (ft lb.)		W/O Inspection Turns To Set
	for Zinc & Galvanized	Stainless Steel	
1/4	6-8	4-7	3-5
3/8	20-25	20-25	3-5
1/2	50-55	40-50	3-5
5/8	90-95	80-90	3-5
3/4	165-175	145-155	3-5
7/8	240-250	N/A	3-5
1	290-300	250-275	3-5


Edge Distance

Embedment (E) in Anchor Diameters	Edge Distance
$E < 6d$ (shallow)	1.75E
$6d \leq E \leq 8d$ (standard)	1.00E
$8d < E$ (deep)	0.75E

Length Selection

Minimum Embedment (A)
 + Attached Material Thickness (B)
 + Nut Height* (C)
 = Total Anchor Length (D)

*Nut height equals anchor diameter.



Recommended Edge Distance & Spacing

Anchor Diameter (In.)	Embedment Depth (In.)	Edge Distance Requirements (In.)
1/4	1-1/4	2-1/4
	2-7/8	2-1/8
3/8	1-3/4	3-1/8
	4-5/8	3-1/2
1/2	2-1/8	3-3/4
	2-1/2	4-3/8
	6-1/4	4-1/2
5/8	2-5/8	4-1/2
	3-1/4	5-1/2
	6-1/4	4-1/2
3/4	3-1/4	5-1/2
	3-3/4	6-1/2
	7-7/8	6
7/8	3-7/8	6-3/4
	8-5/8	6-1/2
1	4	7
	10-1/2	7-7/8

Length Identification Codes

Code	Length of Anchor
A	1-1/2 < 2
B	2 < 2-1/2
C	2-1/2 < 3
D	3 < 3-1/2
E	3-1/2 < 4
F	4 < 4-1/2
G	4-1/2 < 5
H	5 < 5-1/2
I	5-1/2 < 6

Code	Length of Anchor
J	6 < 6-1/2
K	6-1/2 < 7
L	7 < 7-1/2
M	7-1/2 < 8
N	8 < 8-1/2
O	8-1/2 < 9
P	9 < 9-1/2
Q	9-1/2 < 10
R	10 < 11

Code	Length of Anchor
S	11 < 12
T	12 < 13
U	13 < 14
V	14 < 15
W	15 < 16
X	16 < 17
Y	17 < 18
Z	18 < 19

Load Adjustment Factor For Anchor Spacing

Spacing Tension ^fAN (all dimensions in inches)

Anchor Dia. 1/4			Anchor Dia. 3/8			Anchor Dia. 1/2			Anchor Dia. 5/8			Anchor Dia. 3/4		
Embed. Depth	1-1/4	2-1/2	Embed. Depth	1-3/4	4-5/8	Embed. Depth	2-1/8	6-1/4	Embed. Depth	2-3/4	6	Embed. Depth	3-3/4	7-7/8
1-1/8			1	0.50		1			3			2		
1-1/4	0.65	0.70	1-1/4	0.65	0.7	1-1/4	0.60	0.70	2-1/4	0.65	0.75	2-1/4		
1-1/2	0.75	0.75	1-1/2	0.70	0.75	1-1/2	0.70	0.75	2-1/2	0.77	0.76	2-1/2		
1-3/4	0.78	0.79	1-3/4	0.73	0.79	2-1/4	0.83	0.78	2-3/4	0.95	0.78	3	0.60	
2	0.86	0.84	2	0.76	0.80	2-1/2	0.85	0.79	3-1/2	0.93	0.80	4	0.75	0.75
2-1/4	0.87	0.85	2-1/2	0.77	0.83	3	0.90	0.80	4	0.95	0.83	5	0.80	0.80
2-1/2	0.99	0.86	3	1.00	0.87	3-3/8	0.93	0.87	4-1/2	0.96	0.86	5-3/4	0.87	0.83
3	1.00	0.87	3	0.80	0.85	3-3/4	0.99	0.90	5-1/2	0.99	0.93	6-1/4	0.90	0.85
3-3/8		0.88	3-1/2	0.90	0.90	4-1/4	1.00	0.93	6	1.00	0.96	7	1.00	0.90
3-1/2		0.89	3-3/4	1.00	0.93	4-3/4		0.96	7		1.00	8		0.96
3-3/4		1.00	4		0.95	5		0.98				9		0.98
			4-1/2		0.98	6		0.99				10		1.00
			4-5/8		1.00	7		1.00						

DF Supply, Inc. • 10050 Wellman Road • Streetsboro, OH 44241
 Toll-free: (800) 878-7829 • Local: (330) 650-9226 • Fax: (330) 650-9004
 Email: sales@dfsupplyinc.com • Web: www.dfsupplyinc.com